

Advantech AE Technical Share Document

Date	2016 / 11/ 04	SR#	
Category	<input checked="" type="checkbox"/> FAQ <input type="checkbox"/> SOP	Related OS	None
Abstract	How to hide My device and Recycle Bin from Desktop in Windows CE		
Keyword	Hide My device , Recycle Bin , Windows CE		
Related Product	TPC-651T,TPC-1251T,TPC-1551T,TPC-1751T,TPC-1x51WP,WOP-3000,TPC-1x71H		

■ **Problem Description:**

How to hide My device and Recycle Bin from Desktop in Windows CE

■ **Brief Solution - Step by Step:**

1. Go to the startup -> Advantech -> Registry Edit
2. Go to [HKEY_LOCAL_MACHINE\Explorer\Desktop]
3. Delete the {000214A0-0000-0000-C000-000000000046}"=" My device.
 "{000214A1-0000-0000-C000-000000000046}"=" Recycle Bin.
4. Save and reboot it.

Reference