

Advantech AE Technical Share Document


Date	2018/12/11	SR#	1-3624115371
Category	■FAQ □SOP	Related OS	N/A
Abstract	How to disable the user management of CODESYS RTE?		
Keyword	CODESYS		
Related Product	APAX-5580CDS		

■ Problem Description:


This document shows how to disable user management function of CODESYS RTE.

■ Answer:

When users click the  button, the device user management should be activated.




It means user management(Device User Logon) is needed whenever IDE log into RTE. Reference:
https://help.codesys.com/webapp/cds_handling_user_management_on_plc;product=codesys;version=3.5.13.0



If users want to disable this function, please refer to the following step:

1. Use “Administrator” as the User name and Password to log in to device.
2. Right-click a programmable device in the device tree. Click “Reset origin device”. Then, all applications, boot applications, and remnant variables will be deleted from the device.



3. In main menu **Build**, click “Clean all” and **Build** the program again.
4. Login into device and the “Device User Logon” will not be showed anymore.