

Advantech AE Technical Share Document

Date	2019 / 09 / 27	Release Note	☐ Internal ☒ External
Category	☐ FAQ ☒ SOP	Related OS	RISC Ubuntu, Yocto
Abstract	What is the default password for the Linux root account.		
Keyword	RISC Ubuntu, Yocto, TPC-71W, root, password		
Related Product	TPC-71W		

■ **Brief Solution:**

For TPC-71W

Ubuntu

Account: root

Password: 123456

Yocto

Account: root

Password: No password